RELAYS

Nº	USE	CONTACTS	COILS	TYPE	INDEX
A	replay relay	4A	1201	93BB	10C
A1	reels	6A	1201	100BB	5C
A2	left reel	4A	1201	93BB	5C
A3	right reel	4A	1201	93BB	5C
A4	central reel	4A	1201	93BB	5C
B	second coin	4A 2C	1201	138BB	16C
C	start relay	7A 1C	1201	213BB	6C
D	first coin	3A 3C	1201	219BB	16C
DM	10000 points	4A 1C	1201	151BB	1C
F	100 points	4A 1C	1201	151BB	1C
G	1000 points	3A 1C	1201	195BB	1C
H	5000 points	3A	1201	10BB	2C
I	control players	1A 2C 1CO	1202	193BB	16C
J	hold relay	2A 1C 1CO	1202	154BB	16B
K	double bonus	2A 1C	1202	15BB	4C
M	control bumpers	1A 4CO	1202	152BB	5C
O	special replay	5A	1201	12BB	4C
P	button replay	4A	1201	93BB	5C
PC1	reset unit 1st. pl.	5A	1201	12BB	17B
PC2	reset unit 2nd. pl.	5A	1201	12BB	16B
PC3	reset unit 3rd. pl.	5A	1201	12BB	16B
PC4	reset unit 4th. pl.	6A	1201	100BB	16B
Q	add bonus	4A	1201	93BB	11C
R	control reset unit	3A 3C	1201	219BB	15B
S	special	2A 2CO	1201	135BB	4C
T	last ball	1A 1C	1202	141BB	17C
T1	score 1st. pl.	6A	1202	196BB	17C
T2	score 2nd. pl.	7A	1202	197BB	17C
T3	score 3rd. pl.	7A	1202	197BB	17C
T4	score 4th. pl.	7A	1202	197BB	17C
U	bonus	4A	1201	93BB	3C
V	shoot again	2A 2C	1202	164BB	14C
W	30000 points	3A	1201	10BB	2C
X	hole kicker	4A 1C	1201	151BB	3C
Y	balls relay	6A 1C	1201	190BB	6C
Z	control balls return	3A 1C	1201	195BB	6C
F1	tilt	3A 1C	1201-1201	185B	15B-15B
J2	2nd. player	2A 4C 1CO	1201-1201	192B	17B-17B
J3	3rd. player	2A 3C 1CO	1201-1201	191B	17B-17B
J4	4th. player	3A 2C 1CO	1201-1201	207B	17B-17B
Ñ	match relay	1A 5C	1201-1201	223B	15B-17B

OTHER COILS USED

motor	RU-5
scoring unit coils, 05 unit	AC-506
kicker	AC-763
chime coil	AC-682
balls return	AC-655
bumpers, kicking rubber, flippers	AC-1057
add balls played, add replay	B-1005
subtract balls played, subtract replay, hole kicker	B-1006